

**Intended Use**

- For spot lacquering on wood and plastic surfaces, metal and stone.
- For the complete lacquering of small parts like e.g. furniture handles.
- For indoor and outdoor use.

**Characteristics**

- Acrylic-based product.
- Dries rapidly.
- Transparent lacquer.
- Overcoatable with all König touch-up and aerosol lacquers.
- Gloss levels: deep matt 3-4, matt 10-13, silk matt 19-21, silk gloss 35-40, gloss 55-65.
- Good adhesion to many lacquer, plastic and metal surfaces (not to Soft-PVC).
- Good lightfastness and weather-resistance (adequate coat thickness required!).
- Limited PVC-resistance (window/door gaskets).
- Dried up lacquer on the mixing palette is dissolvable and can be mixed well with Brush Pen Covering Lacquer 288.

**Application Notes**

Shake pen well before use – approx. 20 seconds. Rattle of agitator balls must be heard. Take off cap. Hold pen with the tip pointing upwards and de-aerate pen by squeezing area marked 'PRESS' (audible pressure compensation). Now, hold pen with tip pointing downwards over a small wooden board, chip, tissue or cotton cloth and gently squeeze area marked 'PRESS' until lacquer drips onto the base. Stir lacquer drop on the base with the brush tip to achieve an optimum spreading of the liquid medium in the brush tip. Do not touch up too wet – especially when applying fine lines. When brush tip has dried up, either re-pump lacquer or dampen brush tip with Cellulose Thinner. Replace cap after use. Surfaces to be treated must be free of dust, grease and silicone.

After use, clean brush tip while striking off excess material and replace cap firmly.

Recommendation: If pen is not used for a long period of time, clean brush tip with Cellulose Thinner.

**Physical Properties and Shelf Life**

<b>Dust-dry:</b>	after approx. 1-2 minutes
<b>Touch-proof:</b>	after approx. 2-5 minutes (dependent on room temperature and coat thickness)
<b>Lightfastness:</b>	good
<b>Weather resistance:</b>	good
<b>Shelf life:</b>	minimum 2 years (stored at room temperature, in unopened original container)

**Safety Precautions**

Please refer to label and material safety data sheet.

**Disposal**

- Do not allow product to enter drains or watercourses.
- Dispose of pens with the normal household waste only, when completely empty or dried out.
- Leftover material to be disposed of according to the European Waste Code 080111 – *waste paint and varnish containing organic solvents or other dangerous substances*.
- For more detailed information, please refer to the Material Safety Data Sheet for this product or ask your local waste industry office.

**Packaging**

On request.

*Further information and Material Safety Data Sheet on the internet at  
[www.heinrich-koenig.de](http://www.heinrich-koenig.de)*

Although reasonable care has been taken in the preparation of this document, we extend no warranties and make no representations as to the accuracy or completeness of the information contained herein, and assume no responsibility regarding the suitability of this information for the user's intended purposes or for the consequences of its use. Each individual should make a determination as to the suitability of the information for his or her particular purpose(s).



®  
Seit 1892

**Heinrich König & Co. KG**

An der Rosenhelle 5 • D-61138 Niederdorfelden

Phone: 0 61 01-53 60 0 • Fax: 0 61 01-53 60 11

E-mail: [info@heinrich-koenig.de](mailto:info@heinrich-koenig.de)

Issue 08/16